


SCOTTY Teleporter Quick Reference



The **Dial** button displays the Telephone Book. The desired remote station can be selected or the remote station's number can be entered. The videoconference is then started by clicking the **Dial** button.



An ongoing videoconference can be terminated by clicking the **Disconnect** button, shown instead of the **Dial** button.



The **Recorder** button starts the Record and Play mode. This enables audio and video sequences to be saved onto the hard drive and replayed at any time.



The **File Transfer** button starts the SCOTTY File Transfer function - designed to achieve the highest possible data rate.



The **Snap&Send** button captures a still image of the video as JPEG file and sends it to the remote station using the file transfer feature.



With **Snapshot** a still image of the video can be captured. The snapshots are copied into the clipboard and are stored as JPG files.



Preset A to Preset C select one of the individual cameras and audio presets defined in **View | Audio & Video Controls**.



Volume Down decreases the volume of the audio outputs.



Volume Up increases the volume of the audio outputs.



Mute Audio interrupts the transmission of the audio signal. The transmitted audio is resumed by pressing **Mute Audio** again.



Clicking **Mute Video** stops the video transmission, indicated by a red crossed-out camera, and therefore saves network bandwidth.

For details, please refer to the **Software Manual Teleport**, displayed with **Help | Help Topics** or when pressing **F1**. Help files are available under **Manuels** and on www.scottygroup.com.