

# SCOTTY Mobile HD Quick Reference



## Starting the System

Open the case by setting the correct combination and sliding the lock tab to the right.

For AC operation, connect the power cord located on the left side of the unit.

Plug the gooseneck microphone into the “Mic” connector on the back right side.

Connect the network cable to the notebook’s LAN connector on the left side.

Open the notebook and push the power button right beside the keyboard.

## Turning off the System

Shut down: Use the Windows start menu or push the power button.

Immediate power off: Hold the power button for more than four seconds. Warning: This will not shut down Windows, data loss can occur.

For transport, store the gooseneck microphone in its holder in front of the unit.

## Status LEDs

Three LEDs on the front left side of the unit show the system status:

**ACT** Communication box is active. Fast flashing: Battery empty or temperature too high.

**BATT** Communication box battery charge level.

**PWR** Mains power connected.

On top of the notebook’s keyboard, the LEDs display the notebook status:



Power indicator. Flashing: Standby.



Green: SSD indicator. Orange: Heater (option).



Charging indicator. Flashing: battery low.

For details, please refer to the **Equipment Manual Mobile HD**, displayed with **Help | Open Manual**. Help files are available on the system under **Manuals** and on [www.scottygroup.com](http://www.scottygroup.com).